

IQ14Q755 FS01



Use of the chronograph:

Press button “A” once. The chronograph will start.

Press button “A” again. The chronograph will stop.

Press button “B” once. The hands will reset to their original 12 O’clock position.

Resetting the movement:

Pull the crown out completely to adjust the time.

The date can be adjusted by pulling out the crown one step.

If the chronometer’s second hand is out of alignment, it can be reset again by pulling out the crown completely.

Then press button “A” to adjust the seconds hand.

Explanation of the dials and hands:

| | | |
|-------------|---|-------------------|
| Upper left | : | Minute counter |
| Upper right | : | 24-Hour Indicator |
| Below | : | Seconds hand |
| Center | : | Seconds counter |

IQ17Q755 FS01



1. Bediening van de chronograaf:

Druk op knop "A" om de chronograaf te starten.

Druk nogmaals op "A" om de chronograaf weer te stoppen.

Door op knop "B" te drukken wordt de chronograaf op nul gezet.

Tussentijden kunnen gemeten worden door tijdens het lopen van de chronograaf op knop "A" te drukken. Druk hierna nogmaals op "A" om weer verder te gaan met het meten.

2. Het gelijkzetten van de chronograaf:

Als de kroon helemaal uitgetrokken wordt, kan door middel van op knop "A" te drukken de positie van de secondeteller gewijzigd worden, als deze niet op de 12-uurs positie staat.

3. Verklaring van de wijzers en tellers:

- Links boven : de minutenteller
- Rechts boven : 24-uurs aanduiding van de tijd
- Onder : de secondewijzer
- Midden : de secondeteller van de chronograaf.