

IQ13Q847 VD 57B



A

B

Use of the chronograph:

Press button “A” ; the chronograph will start.

Press button “A” again; the chronograph stops.

To reset, press button “B”.

Intermediate times can be read by pressing button “B” once while the chronograph is running.

Press button “B” again to return to the total counted time.

Setting the time:

Pull out the crown completely; By turning the crown the time can be set.

By pulling out the crown just one step, the date can be set.

Aligning the chronograph:

After a battery-change for instance it's possible that the seconds-counter isn't on the “0” position.

To adjust this, pull out the crown completely :

Press button “A”. The 1/10th seconds' counter will move. Keep pressing it till the counter reaches “0”.

Press button “B” to simultaneously set the seconds- and minutes counter.

Once they're both on the “60” position, push the crown back to it's original position.

Explanation of dials and counters:

Top : the 1/10th seconds counter

Left : Minutes counter

Bottom : the seconds-counter

The central hand is the seconds-hand

IQ16Q847 VD 57B



1. Bediening van de chronograaf:

Druk op knop "A" om de chronograaf te starten.

Druk nogmaals op "A" om de chronograaf weer te stoppen.

Door op knop "B" te drukken wordt de chronograaf weer op nul gezet.

Tussentijden kunnen gemeten worden door tijdens het lopen van de chronograaf op knop "B" te drukken. Druk hierna nogmaals op "B" om weer terug te keren naar de verstreken tijd.

2. Het gelijkzetten van de chronograaf en tijd:

Trek de kroon volledig uit. knop "A" zorgt ervoor dat de 1/10e secondenteller verzet kan worden, knop "B" verandert de seconden met daaraan gekoppeld de uren. Blijf op de knoppen drukken totdat de 1/10e seconden- seconden- en minutenteller op "60" resp.

De tijd kan veranderd worden door aan de kroon te draaien als deze volledig is uitgetrokken.

Trek voor de datum de kroon één stapje uit. Gelieve de datum niet te verzetten tussen 9 uur 's avonds en 1 uur 's nachts, dit om beschadigingen aan het datumwerk te voorkomen.

3. Verklaring van de wijzers en tellers:

Boven : de 1/10e secondenteller

Links : de minutenteller

Onder : de secondenteller

De centrale wijzer is de secondenwijzer